



# How to keep your Shears in Shape

**WARNING:** *Loose Tension will cause immediate and destructive wearing of shears.*

- 1- Check & adjust proper tension every day.
- 2- Wipe clean & dry after every haircut.
- 3- Don't cut heavy sections.
- 4- Don't pressure the blades.
- 5- Rest your shears on a padded surface.
- 6- Don't tap comb with scissors to remove hair.
- 7- Always alternate between scissors to prolong edges.
- 8- Clean and lubricate after each day.
- 9- Store separately in protective case.
- 10- Never loan your scissors, everyone cuts and pressures differently!

**(212) 740-0723**  
**[www.SHEARINTEGRITY.com](http://www.SHEARINTEGRITY.com)**